

# pelouze®

## Digital Electronic Hanging Scale

### Model 7710

Capacity: 100 lb. x 2 oz.  
45 kg. x .05kg

### Model 7750

Capacity: 50 lb. x 1 oz.  
22.5 kg. x .02kg

#### How to use this scale

1. Use the top hook to secure the scale to a permanent structure that will enable the scale to provide accurate readings.
2. The scale is powered by three AA batteries (included).
3. To prolong the life of the batteries the scale has an auto-shut-off feature that will activate after 2 minutes of inactivity.
4. Turn the scale on by pressing the "ON" key.
5. The LCD will display 0.00
6. To weigh an object use the bottom hook and secure the object to the hook for accurate reading.
7. If an object is heavier than the weighing range than the scale will indicate an error message or "E"
8. To turn off the scale press the "OFF" button and hold for 2 seconds.

#### Using the TARE Feature

1. Once the scale is on the "TARE" feature can be activated.
2. The "TARE" feature can be used to weigh the contents of a container.
3. To activate the TARE feature press the TARE button once. The LCD will show "tArE" to identify the TARE is activated and than zero.
4. The user can place the item in the tare container to be weighed.

#### Using the HOLD/OFF Feature

1. To hold the weight on the LCD, the user can hold the weight by pressing the "HOLD" button once.
2. The weight will be displayed until either the "HOLD" button is pressed again to de-activate the weight or after two minutes when the automatic shutoff turns the scale off.
3. To turn off the scale press the "OFF" button and hold for two seconds.

#### Using the Memory Feature

1. The scale has the ability to store four weight readings in the scale's memory.
2. To store a weight, press and hold the "MEM" button for three seconds.
3. The weight displayed on the LCD, the MEM icon and weight location will flash two times before storing the weight. The scale will return to normal weight mode after displaying the weight stored in memory for 5 seconds.
4. Remember: The scale has the ability to store four readings. If the memory is full and you want to add another weight to memory, the scale will replace the oldest reading.
5. To view the weights stored in memory, press the MEM button and toggle through lb., memory 1, memory 2, memory 3, memory 4, kg then back to lb.

#### Using the Units Feature

1. The scale has the ability to display both pounds and kilograms.
2. Once the scale is turned on the scale will return to the last used unit of weighing (kilograms or pounds).
3. If the user wants the scale to read in kilograms, the user will need to toggle the MEM/UNITS button. The scale will toggle from pounds through the weights stored in memory, if any, to the kilograms. The sequence is lb., memory 1, memory 2, memory 3, memory 4, kg and back to lb.

**Note:** "Lo BaTT" indicates the battery is weak and should be replaced.

## 1 YEAR LIMITED WARRANTY

#### What Does this Warranty Cover?

Pelstar LLC scales are warranted from date of purchase against defects of materials or in workmanship for a period of 1 year. If product fails to function properly, return the product, prepaid and properly packed to Pelstar. If manufacturer determines that a defect of material or in workmanship exists, customers' sole remedy will be repair or replacement of scale at no charge. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. All parts including repaired and replaced parts are covered only for the original warranty period.

#### Who is Covered?

The original purchaser of the product must have proof of purchase to receive warranty service. Pelstar dealers or retail stores selling Pelstar products do not have the right to alter, or modify or any way change the terms and conditions of this warranty.

#### What is Excluded?

Your warranty does not cover obsolete dials or chips due to postal rate changes, normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, use on improper voltage or current, use contrary to the operating instruction, abuse including tampering, damage in transit, or unauthorized repair or alterations. Further, the warranty does not cover Acts of God, such as fire, flood, hurricanes and tornadoes. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or province to province or jurisdiction to jurisdiction.

#### To get Warranty Service

Make sure you keep your sales receipt or document showing proof of purchase. Call 1 (800) 638-3722 to receive a return authorization. Attach proof of purchase to your defective product along with your name, address, daytime telephone number and description of the problem. Carefully package the product and send with shipping and insurance prepaid to:

Pelstar LLC  
Attention: R/A# \_\_\_\_\_  
Repair Department  
7400 W. 100th Place  
Bridgeview, IL 60455

If your scale is not covered by warranty, or has been damaged, an estimate of repair costs or replacement costs will be provided to you for approval prior to servicing or replacing.